











# FLOORING FIT FOR A LIFETIME OF ADVENTURE.

# **INITIAL CLEANING**

- 1. Remove all loose debris by vacuuming, sweeping, or dust mopping.
- 2. Wet scrub the floor using a buffer or auto scrubber fitted with a soft nylon brush, 3M Blue Cleaner Pad 5300, or equivalent. The floor can also be cleaned by hand using a microfiber mop head. We recommend Diversey Profi Floor Cleaner and Grease Remover (see note) but any neutral pH (7-9) is acceptable. Dilute 10 oz. of solution per gallon of water. Do not flood the floor with water.
- 3. Pick up cleaning solution with a wet vacuum, rinse with clean water. Again, do not flood the floor with water. Wet vac the floor again to remove the rinse water.
- Allow the floor to completely dry before allowing foot traffic.

### FLOOR FINISH APPLICATION

- Apply 2-3 light coats of Diversey Carefree Matte Floor Finish after the initial cleaning.
- 2. Apply the floor finish evenly using a Microfiber Flat Floor Finish applicator.
- While the floor finish is wet, buff the floor using a slow speed buffer fitted with a soft nylon brush (150 rpm-300 rpm).
- 4. Allow each coat to completely dry before applying the subsequent coats.

# **REGULAR MAINTENANCE**

- 1. Keep the floor free from loose debris by sweeping, dust mopping, or vacuuming daily or as needed.
- Damp mop with a microfiber mop or auto-scrubber with a soft nylon brush and 6-10 oz of diluted Diversey Profi Floor Cleaner and Grease Remover.
- 3. Pick up cleaning solution with a wet vacuum, rinse with clean water. Again, do not flood the floor with water. Wet vac the floor again to remove the rinse water.
- Allow the floor to completely dry before allowing foot traffic.

### RESTORATIVE MAINTENANCE

- Remove all loose debris by vacuuming, sweeping, or dust mopping.
- Heavy scrub the floor using an auto scrubber or buffer with a 3M Black Stripper Pad 7200 or equivalent and Diversey LinoSafe Linoleum Stripper solution (dilution ratio 1:4 with water). Keep the floor wet to avoid damage to the floor from the scrub pads. Do not flood the floor with the solution.
- Pick up the solution with a wet vacuum, rinse with clean water. Again, do not flood the floor. Wet vac the floor again to remove the rinse water.
- 4. Allow the floor to completely dry before allowing foot traffic.
- 5. Apply 2-3 coats of new Diversey Carefree Matte Floor Finish as described above in Floor Finish Application.

**Notes:** Diversey products are manufactured by Diversey Inc. For additional information go to www.diversey.com.

